
STRONG electric lifting socket

Model: 462117, 462118, 462119, 462120



Product description:





Important notice: IP44 rating (protection against water splashing from all directions) is applicable in closed state only. Do not install close to sinks and basins, to avoid a possible leak of water inside the product. It is not meant for outdoor use.



WEEE – Waste Electrical and Electronic Equipment

These products must be recycled properly and should not be disposed as household waste. Incorrect disposal may cause environmental damage.

Instructions:

- This product is meant for use as extension connection for power supply, to be embedded into furniture.
- Place the product in a round hole drilled with 65mm in diameter and fasten it
 using the fixing ring. Then plug the cable into socket.
- Activate opening/closing by double tapping the lighting mark on the top glass panel. One short tap can be used to stop the motion.
- Wireless charging is activated by placing the mobile phone on the glass panel.
 Do not put there any items except smartphones with wireless charging support, otherwise this function would keep turning on and off.
- This product is equipped with anti-collision protection, which stops the motion of the upper part, if it's blocked. This applies to both ways, up and down.

Caution:

- CE marking together with Declaration of Conformity confirm compliance with valid EU directives.
- Restrictions and recommendations listed below fully comply to current safety
 measures. Therefore, we recommend all the users to follow preventive safety
 rules valid in their country during installation and maintenance of the device.
- The producer takes no responsibility for any possible damage caused by using the product in a way which doesn't comply to these instructions, mainly by inappropriate installation or by ignoring warnings.
- The producer takes no responsibility for any malfunction, damage or destruction of the product caused by unprofessional change of parts, or by using non original parts.
- Do not disassemble or modify this device, otherwise the warranty will be void.
- Unplug the device before every cleaning. Clean these products with a soft dry or slightly moistened cloth. Avoid using scouring sponges, abrasive or aggressive and/or corrosion causing cleaners.
- Children may use the device only under supervision of a responsible person.
- Do not lay the cable on rough or sharp surface or any places which could cause damage.